



# LX Turbine

# **TURBINE FLOW METERS**

For Liquid Flow Measurement

# Manual

STIX Durchflussmesstechnik GmbH info@stix-flowmeter.de

This Manual provides information and guidance for the installation, operation and maintenance of Lx Turbine Flowmeters.

## **Specification**

Accuracy + / - 0.5 % of reading over Flow Range

+/-2% of reading over Flow Range (Lx 150)

**Repeatability** + / - 0.15 % of reading

Flow Range

| Model  | Litres / min |
|--------|--------------|
| Lx 13  | 2 – 20       |
| Lx 16  | 5 – 50       |
| Lx 19  | 14 – 140     |
| Lx 25  | 27 – 270     |
| Lx 40  | 55 – 550     |
| Lx 50  | 114 – 1140   |
| Lx 80  | 227 – 2270   |
| Lx 100 | 454 – 4540   |
| Lx 150 | 908 – 9080   |

Operating Temperature - 50 to + 282°C

Maximum Pressure Ranges from 20 to 250 bar (ref. to Catalogue)

Pressure Drop 0.25 bar at Maximum Flow

Materials of Construction All 316 Stainless Steel with ANC1A Rotor

**Bearings** Wear Resistant Tungsten Carbide Sleeve

Pick Up The Lx variable reluctance sensor is hermetically sealed

for resistance to moisture and can withstand repeated

thermocycling.

The magnet is resistant to demagnetization.

Output is a low level signal that ranges from 10 mV to 1 V

peak to peak.


A screened twin core signal cable should be used for

connection to the Pick Up.

## **Principle of Operation**

The Lx range of Turbine Flowmeters meet the demand of most liquid measurement applications.

They basically consist of three component assemblies, fitted inside a stainless steel body (locked with retaining rings), which has a Pick Up (variable reluctance sensor) fitted and come in a range of threaded, flanged and tri clamp styles.



The Rotor and shaft assembly (1 off) which is mounted in sleeve bearings, fitted inside Support assemblies (2 off) is turned by the kinectic energy of the flowing fluid at an angular velocity, which in the linear range of the Flowmeter is proportional to the mean axial velocity of the fluid.

The Rotor blades sweep out the full bore of the Flowmeter except for a small tip clearance space. As the blade tips pass the magnetic Pick Up (through the housing wall) they initiate a pulse. Flow rate is determined by the frequency of the pulses and Totalised Flow is obtained by summation of the pulsing electrical signal.

#### Installation

Carry out a visual inspection of the Lx turbine upon receipt, checking for indications of any possible transit damage.

Inspect all packing material carefully for associated components which may have been packed with the shipment.


The stem of the Lx Turbine is marked with a direction arrow to indicate the calibrated direction of flow through the Flowmeter.

Ensure that the Flowmeter is installed in the pipework in the correct orientation to obtain the best reliable operation.

In order to achieve the best electrical signal output from the Flowmeter install well away from current carrying cables, nearby motors and transformers.

The Lx Turbine Flowmeter may be installed horizontally or vertically, but if vertical it is advisable for the fluid flow to be in the upwards direction.

It is good practice to install the Flowmeter with a minimum straight run of 10 pipe diameters upstream of the inlet and 5 pipe diameters following the outlet.



### **Flowmeter By-Pass**

Where possible, such as in a new piping system, it is advisable to include a valved by-pass around the Flowmeter. However, the by-pass connections should not be placed within the recommended straight metering run.

# **Line Purge**

In a newly installed piping system (or one in which fittings have been disturbed) the line should be flushed thoroughly prior to installing the Flowmeter, to minimise possible damage from foreign materials.

#### **Meter Protection**

In Line Strainers (Filters) are recommended for meter protection.

The degree of filtration required depends on the size of the Flowmeter.

The following Table is a guide to assist in the choice of filtration

| Model  | Recommended Mesh Size |
|--------|-----------------------|
| Lx 13  | 200 microns (0.2 mm)  |
| Lx 16  | 200 microns (0.2 mm)  |
| Lx 19  | 200 microns (0.2 mm)  |
| Lx 25  | 300 microns (0.3 mm)  |
| Lx 40  | 300 microns (0.3 mm)  |
| Lx 50  | 300 microns (0.3 mm)  |
| Lx 80  | 500 microns (0.5 mm)  |
| Lx 100 | 500 microns (0.5 mm)  |
| Lx 150 | 500 microns (0.5 mm)  |

To maintain an accurate flow measurement it is essential to ensure that the pipeline bore is completely filled with liquid and that there is a downstream pressure sufficient to prevent flashing/cavitation.

Flashing of the Liquid will result in an indication of flow significantly higher than the actual flow.

To eliminate this condition ensure that the downstream static pressure is at least twice the pressure drop across the meter plus the vapour pressure of the fluid.

#### **Electrical**

The voltage output (A.C. sinewave) generated from the Lx Flowmeter varies from a minimum of 10 mV at the lowest flow on the Lx 13 up to 1 V peak to peak for larger Flowmeters at maximum flow.

A twin core screened signal cable should be used for connection to the Pick Up coil.

Transmission distances up to 50 metres can be achieved without the need for amplification.

Atex Pick Up coils can be fitted for Intrinsically Safe applications.

# **Pick Up Testing**

Testing the Pick Up coil consists of measuring the resistance with an Ohm Meter.

The resistance measured between the two wires from the Pick Up coil should be approximately 1700 Ohms.


#### Maintenance

Once installed, the Lx Flowmeter will require no regular running maintenance apart from a periodic check on the Pick Up coil.


It is recommended that the Flowmeter should be removed from the line periodically and inspected for the presence of dirt or foreign bodies in the internal parts.

The Lx Flowmeter is usually supplied with any of the 101 Range of Electronics, however it can be supplied with just a Signal Conditioning Board such as an Amplifier, Scaler or 4-20 mA Board.

# Amplifier Board Connections



# **Scaler Board Connections**



### 4 - 20 mA Board Connections

